

measurement testing

FIRST:

1. Place a cup on the scale and **Tare (Zero)** it.
2. Run the motor for 10 seconds
3. **Write weight:**

Salt: .8mm

Output #1: 18 g
Output #2: 22 g
Output #3: 20 g
Output #4: 20 g
Output #5: 20 g
Output #6: 26 g
Output #7: 22g
Output #8: 22g
Output #9: 22g
Output #10: 22g
output #11: 24g
Output #12: 22g

Salt: .9mm

Output #1: 20 g
Output #2: 14 g
Output #3: 22 g
Output #4: 22 g
Output #5: 22 g
Output #6: 22 g
Output #7: 28 g
Output #8: 20 g
Output #9: 24 g
Output # 10: 26 g
g

Baking soda:

Output #1: 26 g
Output #2: 26 g
Output #3: 26 g
Output #4: 26 g
Output #5: 26 g
Output #6: 26 g
Output #7: 28 g
(tiny fall)
Output #8: 28 g
(fall)
Output #9: 22 g
Output #10: 28 g
Output #11: 26 g

Cinnamon:

Output #1: 8 g
Output #2: 4 g
(clogged)
Output #3: 6 g
Output #4: 6 g
Output #5: 6 g
Output #6: 6 g
Output #7: 6 g

Precise measurements:

1. Run continuously until the powder starts falling out. **time that!**
2. Run the motor for exactly 10 Seconds.
 - Weigh the total pile.
 - $\text{Total Weight} / 10 = \text{Grams per Second (flow rate)}$

- Target Weight (g) / Grams per Second = Seconds to Run

Salt:

Total weight: 22 g
Flow rate: 2.2
grams/second

Target (1/4 tsp): ~1.5
grams

**Seconds to run: 1.5 /
2.2 = ~ .69 seconds**

Target (1/2 tsp): ~2.0
grams

**Seconds to run: 2.0 /
2.2 = ~1.38 secs**

Target (1 tsp):
~6.0grams

**Seconds to run: 6.0 /
2.2 = ~ 2.76 secs**

Target (1/2 tbsp): ~7.2
grams

Seconds to run: 7.2 /

Target (1 tbsp): ~14.4
grams

Seconds to run: 14.4 /

Baking soda:

Total weight: 26 grams
Flow Rate: 2.6 grams /
second

Target (1/4 tsp): ~1.2
grams

**Seconds to run: 1.2 /
2.6 = ~ 0.46 seconds**

Target (1/2 tsp): ~2.4
grams

**Seconds to run: 2.4 /
2.6 = ~.92 secs**

Target (1 tsp):
~4.8grams

**Seconds to run: 4.8 /
2.6 = ~1.85 secs**

Target (1/2 tbsp): ~7.2
grams

**Seconds to run: 7.2 /
2.6 = ~2.77**

Target (1 tbsp): ~14.4
grams

**Seconds to run: 14.4 /
2.6 = ~5.54 secs**

Cinnamon:

Total weight: 6 g
Flow rate: .6 g/s

Target (1/2 tsp): ~4
grams

**Seconds to run: 4 / 0.6
= 6.67 seconds**

Hitting 1/4 tsp

Formula: Target Weight / grams per second = seconds to run

Salt:	Baking powder:	Baking soda:	Cinnamon:
Target weight: 1.5 g (1/4 tsp)	Target weight: 1.2 (1/4 tsp)	Total weight: 1.2 g (1/4 tsp)	Total weight: .65 g
Seconds to run: ~1000 ms	Seconds to run: 1000ms	Seconds to run: ~seconds	Seconds to run:
1200ms	660 ms	460ms + 200ms	Output #1:
Output #1: 1/8 tsp	Output #1: 1/8 tsp	660 ms	Output #2:
Output #2: 1/8 tsp	Output #2: 1/8 tsp	Output #1:	Output #3:
1100ms	1000 ms	Output #2:	Output #4:
Output #3: 1/4tsp	Output #3: 1/4 tsp	Output #3:	Output #5:
Output #4: overflow	Output #4: 1/8 tsp	Output #4:	Output #6:
Output #5: overflow	Output #5: overflow	Output #5:	Output #7:
	Output #6: 1/4 tsp	Output #6:	Output #8:
1000ms	Output #7: 1/8 tsp	Output #7:	Output #9:
Output #6: 1/4 (tiny under)	Output #8: 1/8 tsp	Output #8:	
Output #7: 1/4 (tiny under)	Output #9: overflow	Output #9:	
Output #8: 1/8	tap test:		
Output #9: overflow	Output #1: 1/8 tsp		
Output #10: 1/4 tsp			

Output #11: 1/4
tsp

Output #12: 1/4
tsp

Output #13: 1/4
tsp

Output #14: 1/4
tsp

Target weight:
1.5 g (1/2 tsp)

Seconds to run:
~1800 ms
(above*2-.2)

Output #1: 1/2
tsp

Output #2: 1/2
tsp

Output #3: 1/2
tsp (tiny under)

Output #4: 1/2
tsp

Output #5: 1/2
tsp (little over)

Output #6: 1/2
tsp

Output #7: 1/2
tsp

Target weight: 6
grams (1 tsp):

Output #2: 1/8
tsp

Output #3:
overflow

Output #4: 1/8
tsp

Output #5:
overflow

Output #6: 1/8
tsp

Output #7:
overflow

with agitator:

Output #1:
overflow, but 1/4

Output #2: 1/8

Output #3: 1/8

Output #4:
overflow, but 1/4

Output #5: 1/4

Output #6: 1/4
(tiny over)

Output #7: 1/4

Output #8: 1/4

Output #9: 1/4
(tiny over)

Output #10: 1/4

Output #11: 1/4
(tiny under)

Seconds to run:

~3400 ms

(above*2-.2)

Output #1: 1 tsp

Output #2: 1 tsp

Output #3: 1 tsp

Output #4: 1 tsp
(tiny over)

Output #5: 1 tsp

Output #6: 1 tsp
(tiny over)

Output #7: 1 tsp

time =

(800ms)x +

(200ms)

**x = amount of
1/4 tsp in the
amount**

Target weight:

14.4 grams (1
tbsp):

Seconds to run:

~9800 ms

Output #1: 1
tbsp

Output #2: 1
tbsp

Output #3: 1
tbsp

Target weight:

2.4 (1/2 tsp)

Seconds to run:

1800ms

Output #1: 1/2
tsp (tiny over)

Output #2: 1/2
tsp (tiny over)

Output #3: 1/2
(tiny over)

1700ms

Output #4: 1/2
tsp (teeny over)

Output #5: 1/2
tsp

Output #6: 1/2
tsp

Output #7: 1/2
tsp (teeny over)

Output #8: 1/2
tsp

Output #9: 1/2
tsp (teeny over)

Output #10: 1/2
tsp

Target weight:

4.8 (1 tsp)

Seconds to run:

3100ms

Output #1: 1 tsp

Output #4: 1
tbsp

Output #5: 1
tbsp

Output #2: 1 tsp

Output #3: 1 tsp

Output #4: 1 tsp
(tiny over)

Output #5: 1 tsp

Output #6: 1 tsp
(tiny over)

Output #7: 1 tsp
(tiny over)

Output #8: 1 tsp
(tiny under)

Output #9: 1 tsp

Output #10: 1
tsp (tiny under)

Target weight:
14.4 (1 tbsp)

Seconds to run:

8700 ms

Output #1: 1
tbsp (tiny under)

Output #2: 1
tbsp (tiny under)

Output #3: 1
tbsp (tiny under)

8900ms

Output #4: 1
tbsp

Output #5: 1
tbsp

Analyze:

If numbers are close? → done.

If wildly different → it is pulsing and need something to restrict flow or 12 flights

SALT - .8mm Tolerance: **time = (800ms)x + (200ms)** → **x = amount of 1/4 tsp in the amount**

time	measurement
1000 ms	1/4 tsp
1800 ms	1/2 tsp
3400 ms	1 tsp
9800	1 tbsp

BAKING SODA/POWDER - .6mm Tolerance w/ agitator

time	measurement
1000 ms	1/4 tsp
1800ms	1/2 tsp
3100ms	1 tsp
8700 ms	1 tbsp

archive:

Baking soda:

Output #1: 6 g

Output #2: 8 g

Output #3: 6 g

Output #4: 10g

Output #5: 8 g

Output #6: 10 g

Output #7: 6 g

Output #8: 6 g

Output #9: 8 g